PREMIER PROPERTY MANAGEMENT, INC. MAINTENANCE TIPS

**Try these simple DIY repairs before you call for maintenance

ISSUE:	Electrical outlets are not working	ISSUE:	Toilet Problems?	
Most common cause:			1. Toilet is clogged or running.	
*A GFCI outlet has likely tripped.		WHAT TO DO:		
WHAT T	 There are a couple of reasons a GFCI oulet will trip: Overloaded circuit (too many electrical objects plugged into one circuit) Occasionally, GFCI outlets can fail GFCI outlets are often found next to the water sources in your home. There are a few likely places you can find a GFCI outlet, including near your kitchen sink, in your bathroom(s), in your garage, or on your patio. A GFCI outlet is recognizable because is has two (2) buttons in the center, one to 'TEST' and one to 'RESET'. AT TO DO: Go to each GFCI outlet in your home and tress the 'TEST' buttonwhich will cause the RESET button to pop out usually with an audible click then press the RESET button on each GFCI outlet and the problem should be solved. *Sometimes very old houses will not have any GFCI outlets. Instead they will have one or two circuit breakers that are GFI breakers. In this case you must push the curcuit breaker lever all the way to the OFFI position until you hear an audible CLICK. That should solve the problem. 	ISSUE:	r toilet is clogged, use a plunger to solve this problem. turn off he water valve under the toilet tank to keep is from owing. With the drain hole covered completely with the rubber of plunger, repeatedly push up and down vigorously withough ing the seal. Once you release the suction the clog should dislodge vater should drain as usual If your toilet is running, first try og the handle. If that does not solve the issue, thenlift the cover off ank and check that the chain, valves, and tube are all properly forted. Make sure the chain is not tangled and that the flapper is in prrect position. These easy steps should solve these issues. If all alls turn off the water to the toilet. age disposal not working? garbage disposal is likely clogged. e are a couple of reasons why a disposal will stop working:	
			 It is not being used properly. Foods such as egg shells, coffee grounds, potatoes, and pasta are fibrous and expand when wet. These items should never get put down your disposal. It's possible a fuse has blown. 	
ISSUE:	No Heat?	WHAT TO	DO:	
	1. When is the last time you changed your filter? A clogged filter will cause the furnace to starve for air and the limit switch to trip.		Check the bottom or back of the disposal and press the reset button. Use a flashlight and look down inside the disposal through the sink drain and make sure there is not anything lodged in there jamming the	
WHAT TO DO:			blades. There is also a fitting for a $1/4$ " Allen wrench on the bottom	
	Remove the clogged filter - usually after a few minutes the minit switch will reset and the furnace will go back to working as normal. Install a new to prevent the dust and and dirt build up on the internal workings of the furnace which will cause it to fail. **It is also very important that you are also using the correct size filter in the furnace.		center of the disposal. Use this to turn the blades back and forth until they turn freely. If it is still humming, that means it is jammed. If it is rattling, that means there is something small jammed inside. Make sure that your disposal is completely off, and try using a flashlight and needle nose pliers to pull out the offending object.	