

Canon Tintenpatronen / Druckerpatronen

Patrone	Drucker	original	kompatibel
BC-02 black	BJ100, BJ200, BJ200E, BJ230, BJC210, BJC240, BJC250	✓	✓
bci-15 black	i70, i80	✓	✓
bci-15 tricolor	i70/ i80	✓	✓
BX-03	Fax B100, B110, B115, B150, B155, Faxphone B45, B540, B550, B60, B640, Telekom T-Fax 360, 361, 4200, 4300	✓	✓
cl-38 color	ip2500, ip2600, MX300, MX310, MP190, MP210, MP220	✓	✓
cl-41 color	Pixma iP1600, iP1700, iP2200, iP2500, iP2600, iP6210D, iP6220D, MP150, MP160, MP170, MP180, MP190, MP210, MP220, MP450, MP460, Pixma MX300, MX310	✓	✓
cl-51 color	Pixma iP2200, iP6210 Serie, iP6220-Serie, Pixma MP150, MP160, MP170, MP180, MP450, MP460, MX300, MX310	✓	✓
cl-511	IXMA iP 2700, PIXMA MP 240, PIXMA MP 250, PIXMA MP 260, PIXMA MP 270, PIXMA MP 280, PIXMA MP 490, PIXMA MP 495, PIXMA MX 320, PIXMA MX 330, PIXMA MX 340, PIXMA MX 350, PIXMA MX 360, PIXMA MX 410, PIXMA MX 420	✓	✓
cl-513	PIXMA iP 2700, PIXMA MP 240, PIXMA MP 250, PIXMA MP 260, PIXMA MP 270, PIXMA MP 280, PIXMA MP 490, PIXMA MP 495, PIXMA MX 320, PIXMA MX 330, PIXMA MX 340, PIXMA MX 350, PIXMA MX 360, PIXMA MX 410, PIXMA MX 420	✓	✓
cl-541 color	MG2150/MG225/MG3150/MG3250/MG4150/MG4250/MX375/MX435/MX517	✓	✓
cl-541XL color	MG2150/MG225/MG3150/MG3250/MG4150/MG4250/MX375/MX435/MX518	✓	✓

Canon Tintenpatronen / Druckerpatronen

Patrone	Drucker	original	kompatibel
cl-546 color	iP2850/MG2450/MG2455/MG2550	✓	✓
cl-546XL color	iP2850/MG2450/MG2455/MG2550	✓	✓
cli-521 photoblack/color	Canon MP540, MP550, MP560, iP3600, iP4600, iP4700, MP980, MP620, MP630, MP640, MP990, MX860	✓	✓
cli-526 photoblack/ color	Pixma iP4850/iX6550/ MG5150/ MG5250/ MG6150/ MG8150/ MX886	✓	✓
cli-551 photoblack / color	Pixma iP7250/MG5450/MG6350/MX725/MX925	✓	✓
cli-551XL photoblack / color	Pixma iP7250/MG5450/MG6350/MX725/MX925	✓	✓
cli-571 black	Pixma MG 5700 Series/5750 Series/6800 Series/6850 Series/7700 Series/7750 Series	✓	✓
cli-571XL bk	Pixma MG 5700 Series/5750 Series/6800 Series/6850 Series/7700 Series/7750 Series	✓	✓
cli-8 photoblack / color	PIXMA MP500, MP510, MP520, MP530, MP600, MP600R, MP610, MP800, MP800R, MP810, MP830, MP960, MP970, MX700, MX850, iP3300, iP3500, iP5200, iP4200, iP5300, iP4300, iP5500, iP4500	✓	✓
Original-Druckkopf Canon QY6-0059	Pixma iP4200/ MP500/ MP530	✓	✓

Canon Tintenpatronen / Druckerpatronen

Patrone	Drucker	original	kompatibel
Original-Druckkopf Canon QY6-0061	Pixma iP4300/ iP5200/ MP600/ MP800/ MP830	✓	✓
Original-Druckkopf Canon QY6-0073	Pixma iP3600/ MP540/ MP550/ MP560/ MP620/ MX620/ MX860/ MX870/ MG5150	✓	✓
pg-37 black	iP2500, iP2600, MX300, MX310, MP190, MP210, MP220	✓	✓
pg-40 black	Pixma iP1600, iP1700, iP2200, iP2500, iP2600, iP6210D, iP6220D, MP150, MP160, MP170, MP180, MP190, MP210, MP220, MP450, MP460, Pixma MX300, MX310	✓	✓
pg-50 black	Pixma iP2200, iP6210 Serie, iP6220-Serie, Pixma MP150, MP160, MP170, MP180, MP450, MP460, MX300, MX310	✓	✓
pg-510	PIXMA iP 2700, PIXMA MP 240, PIXMA MP 250, PIXMA MP 260, PIXMA MP 270, PIXMA MP 280, PIXMA MP 490, PIXMA MP 495, PIXMA MX 320, PIXMA MX 330, PIXMA MX 340, PIXMA MX 350, PIXMA MX 360, PIXMA MX 410, PIXMA MX 420	✓	✓
pg-512	PIXMA iP 2700, PIXMA MP 240, PIXMA MP 250, PIXMA MP 260, PIXMA MP 270, PIXMA MP 280, PIXMA MP 490, PIXMA MP 495, PIXMA MX 320, PIXMA MX 330, PIXMA MX 340, PIXMA MX 350, PIXMA MX 360, PIXMA MX 410, PIXMA MX 420	✓	✓
pg-540 black	MG2150/MG225/MG3150/MG3250/MG4150/MG4250/MX375/MX435/MX515	✓	✓
pg-540XL black	MG2150/MG225/MG3150/MG3250/MG4150/MG4250/MX375/MX435/MX516	✓	✓
pg-545 black	iP2850/MG2450/MG2455/MG2550	✓	✓
pg-545XL black	iP2850/MG2450/MG2455/MG2550	✓	✓

Canon Tintenpatronen / Druckerpatronen

Patrone	Drucker	original	kompatibel
pgi 2500 black	Maxify iB4050,4150/MB5050, MB5150, MB5155, MB5350, MB5450, MB5455	✓	✓
pgi-1500 black	Maxify MB2050, MB2250, MB2155, MB2350, MB2750, MB2755	✓	✓
pgi-1500 c/m/y	Maxify MB2050, MB2250, MB2155, MB2350, MB2750, MB2755	✓	✓
pgi-2500 c/m/y	Maxify iB4050,4150/MB5050, MB5150, MB5155, MB5350, MB5450, MB5455	✓	✓
pgi-5 black	PIXMA MP500, MP510, MP520, MP530, MP600, MP600R, MP610, MP800, MP800R, MP810, MP830, MP960, MP970, MX700, MX850, iP3300, iP3500, iP5200, iP4200, iP5300, iP4300, iP5500, iP4500	✓	✓
pgi-520 black	Canon MP540, MP550, MP560, iP3600, iP4600, iP4700, MP980, MP620, MP630, MP640, MP990, MX860	✓	✓
pgi-525 black	Pixma iP4850/ iX6550/ MG5150/ MG5250/ MG6150/MG8150/ MX885	✓	✓
pgi-550 black	Pixma iP7250/MG5450/MG6350/MX725/MX925	✓	✓
pgi-550XL black	Pixma iP7250/MG5450/MG6350/MX725/MX925	✓	✓
pgi-570 black	Pixma MG 5700 Series/5750 Series/6800 Series/6850 Series/7700 Series/7750 Series	✓	✓
pgi-570XL bk	Pixma MG 5700 Series/5750 Series/6800 Series/6850 Series/7700 Series/7750 Series	✓	✓