



**Installation Instructions for Intrigue Series
Citation, Elegant, Epic, Large Concord,
Large Metro and Mystique Shepherd's
Crook Post Top Mount**

NOTE: Keep these instructions for future reference.

CAUTION

RISK OF FIRE. Use only the type and wattage lamp specified on the lamp label. For supply leads use wire suitable for 75°C. A maximum of four (4) No. 14 awg through branch circuit conductors suitable for at least 75°C are permitted in the tube base (two in, two out)

MOUNTING

Shepherd's Crook Pole Mount (PTS)

Feed wires into and through shepherd's crook (item 1) and then proceed to slide shepherd's crook into pole tenon and secure by tightening the three (3) provided set screws (item 2). Loosen the four (4) provided set screws (item 5) and remove cover (item 4) from fixture. Pull wires through the hole in the top of the cover (item 4) and attach cover (item 4) to shepherd's crook (item 1) and secure by tightening the three (3) provided set screws (item 3).

Attach wires (customer supplied) to corresponding leads from ballast. White wire (common), black wire (lead), and green wire (ground).
(120/208/240/277 or 347V)

Warning: RISK OF FIRE AND ELECTRICAL SHOCK. ALL OTHER VOLTAGE LEADS MUST BE INSULATED.

NOTE: HID FIXTURE IS SUPPLIED FROM FACTORY PRE-WIRED FOR 277V. IF A DIFFERENT VOLTAGE IS REQUIRED, CAP UNUSED 277V LEAD (FROM BALLAST) AND CONNECT SUPPLY WIRE TO DESIRED VOLTAGE LEAD.

WARNING

RISK OF FIRE AND ELECTRIC SHOCK. This product is to be installed by a qualified electrician only, and in accordance with local, state and national electrical codes. Make certain the electrical supply is OFF before starting installation.


Attach fixture cover (item 4) and secure with four (4) provided set screws (item 5). Install shade (item 6) and secure with four (4) provided set screws (item 7). Slide globe (item 8) over lamp and turn clockwise in socket plate to secure.

LAMPING

Assemble lamp provided into the lamp socket. CAUTION: RISK OF FIRE. USE ONLY THE TYPE AND WATTAGE LAMP SPECIFIED ON THE LAMP LABEL IN THIS LIGHTING FIXTURE.

MAINTENANCE

To maintain light efficiency and prevent fixture overheating, diffuser must be kept clean and free of dirt, dust, leaves and trash. Periodic cleaning is recommended.



Shepherd's Crook Post Top Mount - PTS

Three Year Products Warranty -- (Limited Type)

Intrigue Lighting, LLC., warrants its products against defects in material and workmanship. At the company's discretion, and without charge, Intrigue Lighting, LLC. will either repair or replace any properly installed Intrigue Lighting, LLC. manufactured product which fails under normal operating conditions within three years from the date of invoice, provided it is returned to the factory (after authorization), transportation prepaid, and our inspection determines it to be defective under terms of this warranty.

The warranty covers only equipment manufactured by Intrigue Lighting, LLC. and does not extend to transportation, installation, or replacement charges at buyer's facility; nor does it apply to any other equipment of another manufacturer used in conjunction with Intrigue Lighting, LLC. equipment. No other warranty, expressed or implied, exists beyond that included in this statement.