

**Four Lineside Terrace Backs - ASSEMBLY INSTRUCTIONS**

**Contents.** The kit comprises SHEET 1 & SHEET 2, the illustrated SUPERQUICK header card, ACCESSORIES CARD A, the long ACCESSORIES B sheet, an acrylic glazing sheet and this ASSEMBLY INSTRUCTIONS sheet.

**Tools.** A sharp modelling knife and a steel rule are essential. Bulldog clips, a few rubber bands and 'Sellotape' might be useful to secure parts of the kit while glue is drying.

**Glues.** Most liquid glues are suitable. PVA glue is recommended, it becomes matte and almost transparent when dry, although in cold conditions the glue tends to dry white. A solvent glue like 'Evostick' or 'UHU' is also recommended as it is quick to dry but can present problems when touching up model with water based paint. For gluing areas of paper, such as lining pieces, it is recommended that PVA be thinned or

that a spray or a spreadable solvent glue is used.

**Card-mounted components.**

Separate the parts only when called for by nicking with the knife at uncut points.

**Scoring.** Red arrows signal a fold back. Blue arrows signal a fold forward.

Where the cutter lines are marked with arrows, they are scored only (i.e. only partly cut through). Here the component is intended only to be bent or folded. Sometimes additional scoring with the knife may be necessary, so that the board bends at the fold line without too much resistance. If the fold line is cut through, a repair can be made by gluing a thin paper strip to the back.

**Waste.** Waste card is indicated by the symbol **W**

**Windows.** The Glazing Sheet has 20 window pieces divided by dotted lines. There are two methods of glazing, which can be combined for a really durable result:

(1) Lay down the window piece face up. Apply glue to the back of the wall around the window aperture and the lower the wall onto the window piece. This method is easier for small windows and permits adjustment - correct the alignment before the glue sets and wipe excess glue from the window surface with a damp paintbrush or tissue.

(2) Apply narrow strips of 'Sellotape' along two sides of the unprinted back of the window piece. Lay the window piece down as before and lower the wall onto the partly exposed 'Sellotape'. When the window is attached to the wall, rub down the tape and apply further strips to the remaining two sides of the

window piece.



**Finishing.** The appearance of the completed model will be greatly improved if all exposed edges are touched up with paint. It is important that there is no glue on exposed edges.

**Options.** This kit, when completed, will provide you with the back sections of four terraced houses, to stand in low relief along a walled edge to your layout. It is designed to combine with Terraced House Front kit C6 to form an entire row of 4 terraced houses. This terrace can be completed by adding the Terrace Corner kit C7 at each end.

The following instructions are divided into two sections; SECTION 1 - a complete low relief kit. SECTION 2 - the construction of a terrace, incorporating additional C5 kits. SECTION 3 - the incorporation of kit C6 to create a completed row of four terraced houses.


**1** Divide the two SHEET halves. From SHEET 2 take the BACK WALL, complete with top & bottom TABS. Note the red arrows signalling fold lines. Remove the PAVING and the window waste pieces and glaze the window apertures. Fold forward and glue flat the four vertical blue arrowed TABS, having scored along the perforation on the reverse side. Fold back the main TABS but **do not** glue.

GLAZING PIECES NOT ILLUSTRATED




BACK WALL

**2** REAR WALLING SECTION



From SHEET 1 take the two REAR WALLING SECTIONS complete with bottom TABS. Remove waste, retaining the CHIMNEY TOP pieces and glaze the window apertures. From SHEET 2 take BACK DOOR pieces - again remove waste and glaze. Fold but **do not** glue the bottom TABS and glue the doors in place. From SHEET 1 take the REAR FORMERS and glue folded walling sections around formers as illustrated.



REAR WALLING SECTION



REAR FORMER

DOOR

TAB

**3** From SHEET 1 take the RIGHT and LEFT WALLS complete with their surrounding TABS. These walls include a side of the chimney stack at the summit. Fold and glue flat the three upper tabs leaving the BOTTOM TAB folded but **not** glued. Glue the shorter vertical edge to the back edge of the REAR wall making sure the two parts are square and level. From SHEET 2 take the two CORNER BRACKETS and glue in place, securing the end walls. From SHEET 2 take the two part SUPPORT BEAM, fold slightly and glue into position further securing the exposed edges of

GLAZING PIECES NOT ILLUSTRATED



SUPPORT BEAM

RIGHT WALL

LEFT WALL


CORNER BRACKET

**4** Take the completed REAR WALLING SECTIONS and glue in place around the folded tabs on the face of the REAR WALL. Ensure that the top and bottom edges are level and square.


**5** Guttering is best folded before being cut out of the ACCESSORIES card this will minimise distortion along its length. From ACCESSORIES CARD A cut roughly round the GUTTERING. Lightly score and fold before trimming to lines. Glue flat as illustrated then curl black band around edge of ruler to form gutter duct.



GUTTERING




From SHEET 1 take two pairs of REAR ROOFS complete with ridge wall strips and a TAB, attached to one of each pair. Fold the wall strips forward, having scored along the perforation on the reverse side. Fold back and glue flat the TABS. Glue together each pair and line edge with four of the longer lengths of guttering as illustrated. Glue in position to the middle of the underside of the two ROOF FORMERS, having removed the notches in each marked in black.




From SHEET 2 take MAIN ROOF, in two parts complete with a ridge wall strip at each end. Fold forward the wall strips, having scored along the perforation on the reverse side. Again as illustrated, line front edges with remaining guttering.

Position the roofs and glue in place together. The wall edges of the main roof should be inside and level with the angled TOP TABS on the RIGHT WALL and LEFT WALL.


- 7** From ACCESSORIES B sheet cut out CHIMNEY POTS, coil and glue as illustrated. Cut twin pot pieces in half. Cut out the CHIMNEY STACKS; fold and glue into position as illustrated. Complete with the CHIMNEY TOPS (from SHEET 1) and the CHIMNEY POTS.



- 8** From SHEET 1 take RIDGE WALLING pieces and sandwich the FILLER piece. Similarly from SHEET 1 take ROOF WALLING pieces and again glue them each side of the ROOF WALL FILLER (from SHEET 2) with the walling pieces. Glue into place on the roof as illustrated. From ACCESSORIES CARD A take the BRICK RIDGE STRIPS and line the walling on the ridges and sides as illustrated.




- 9** From SHEET 1 take the four pairs of GATE WALLS. From ACCESSORIES CARD B take YARD GATES, cut out and glue centrally to the GATE WALL pieces as illustrated, fold and glue flat to create pairs of gates. Glue in place at the yard entrances. If gates are to be positioned at ends of a terrace block, divide one of the pairs in two by cutting down the middle of the wall with a sharp knife as illustrated.




- 10** Walling and paving pieces are included in this kit to create back yard detailing; a cobbled lining sheet adds detail to a section of alley-way that could run along the rear of the houses.

From SHEET 2 take PRIVY ROOFS, WALLS and FORMER pieces, also take the two longest DIVIDING WALL pieces. Assemble each privy and glue as illustrated.



From SHEET 1 take four YARD PAVING pieces.


Glue the four large paving pieces into grooves along the base of the walls, set firmly and squarely into the corners, (there should be space for the dividing walls between the central paving pieces). From ACCESSORIES CARD B cut out and cut to edge YARD SURFACE, glue to underside edge of rear wall sections and yard paving pieces. From SHEET 2 take four long DIVIDING WALL pieces; two are to be glued together while the outside walls will be lined with DIVIDING WALL LININGS from ACCESSORIES CARD A. Similarly, take four short DIVIDING WALL pieces and glue together in pairs. Arrange and glue into position all the wall sections, dividing up the terrace into yards as illustrated. Glue into position the four YARD PAVING EDGES between each dividing wall.





## SECTION 2 - CONSTRUCTION OF TERRACE (INCORPORATING ADDITIONAL C5 KITS)

- 1** This kit is a complete low relief kit but it is also designed to incorporate other C5 kits to form a back of an extended terrace. IT IS RECOMMENDED THAT ALL THE C5 KITS REQUIRED FOR THE TERRACE BE CONSTRUCTED TOGETHER.

In order to minimise the appearance of a join when combining two kits, the length of the front walls needs to be reduced by 2mm overall. Whilst following the instruction overleaf, it is recommended that one 2mm strip of one front wall (with guttering downpipe edge) is scored deeply and folded as a tab, removing one of the top notches as illustrated. This will create a groove to which the adjacent wall (with a notch) be glued against.




- 2** Continue to follow overleaf to instruction 3, then take one END WALL and remove the angled TOP TAB. Glue the END WALL centrally (to the notch) behind the join and support with two CORNER BRACKETS either side.




Continue to follow instructions overleaf, fixing roofs in position along the terrace as illustrated. The result should leave a single join down the front that will be disguised by the guttering downpipe detail.

## SECTION 3 - THE COMPLETE BUILDING (INCORPORATING SUPERQUICK KIT C6)

Developing the kit into a complete set of four terrace houses requires the incorporation of almost all of SUPERQUICK kit C6. This kit includes a complete END WALL in C6 SHEET 1, which can be used to replace two low relief end walls on one exposed end, avoiding an unsightly join. However a second end wall (maybe one that is hidden from view) needs to be constructed. Using the complete wall as a guide, cut along a line that would run down one edge of the chimney and through the bottom tab, effectively removing the chimney stack from one of the walls. Remove side tab of other end wall and glue together. Strengthen with the use of a scrap of card cut to length.



Continue with guidelines in SECTION 1 until instruction 4 then take the two MAIN ROOFS from each kit complete with walling strips and remove the supporting narrow roof pieces. Join the two roofs with a strip of paper cut to length and glued. Continue with instructions overleaf.



**Please note** that a terrace of eight houses will come with two complete END WALL pieces; and that if a Terrace Corner kit C7 is being added to the terrace it includes a complete END WALL making this construction unnecessary.